PRÓCHEM

Product Specification Sheet

C255 PRORINSE

LABEL INSTRUCTIONS

Product Description & Directions for Use:

An acidic rinse agent for neutralising alkaline residues of floor polish stripper, before applying new emulsion polish. The use of Prorinse helps prevent 'powdering' and problems with the adhesion and durability of the new polish which can be caused by alkaline cleaner or stripper residues.

For professional and industrial use only.

Remove stripper and soil slurry with wet pick-up vacuum. Dilute 50ml Prorinse per litre of water (1 to 20). Apply solution evenly to floor with mop, then allow floor to dry before application of Proshine emulsion polish.

- Acid rinse agent for neutralising alkaline emulsion polish floor stripper
- Prevents reaction and powdering of new polish.
- Orange liquid with mild odour.

pH Concentrate: 2.5 pH Diluted: 3.5 to 4.0

DANGER. Causes serious eye damage. Causes skin irritation. May be corrosive to metals.

Keep out of reach of children. Wear protective gloves / protective clothing / eye protection / face protection. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER / doctor. IF ON SKIN: Wash with plenty of water. Absorb spillage to prevent material damage.

Please consult the Safety Data Sheet before using this product.

This product is intended for professional use only. The information given is intended to be of assistance to users but is without guarantee. Variations can occur in application and users are advised to conduct their own tests. Suggestions for use neither give nor imply any guarantee as to the intended use.

Product Name: PRORINSEProduct Code: C255Manufacturer: Prochem Europe Ltd., Oakcroft Road, Chessington, Surrey KT9 1RH, UK.Telephone No: 020 8974 1515 (UK) +44 20 8974 1515Website: www.prochem.co.ukEmail: sales@prochem.co.uk

